# 800 Series Plug-in Detector





### **General Description**

The 800 series are 2-wire conventional low profile detectors . It is a low cost and high reliability series. A LED will be latched on to locally indicate alarm. The (-) in and (-) out terminals are short-circuited inside the detectors. When the detector is mounted it will continue the wire to the next device or EOL resistor. When it is removed, the wire will be open for wiring supervision.

**881** Model 881 is a 2-wire conventional ionization smoke detector that uses a state-of-the-art sensing chamber. These detectors are designed to provide open area protection and to be used with compatible listed control panels only.

**882** Model 882 is a 2-wire conventional photoelectronic smoke detector that use a state-of-the-art optical sensing chamber. This detector is designed to provide open area protection and to be used with compatible panels only.

**885** Model 885 is a 2-wire conventional fixed temperature heat detector. These detectors are designed to provide open area protection and to be used with compatible listed control panels only. The 800 series are UL listed.

# **Specifications**

Size

Height (With base): 5.5 cm (Ionization), 4.8cm (Heat), 5.0cm (Photoelectronic)

Diameter: 10.2 cm

Operating Temperature Range: 32° to 100°F (0° to 38°C) for heat, 32° to 120°F (0° to 49°C)

for lonization, photoelectronic

Operating Humidity Range: 5%-95% RH

Latching Alarm: Reset by momentary power interruption

Max Air Velocity: 4000ft/min (Photoelectronic), 2000ft/min (Ionization)

Operating Voltage:  $15 \sim 30 \text{VDC}$ Standby Current:  $\leq 50 \,\mu\text{A}$ 

Alarm Current: min 2mA @ 3.1VDC

max 80mA @ 6.5VDC


Maximum Ripple Voltage: 4 Volts peak to peak

Sensitivity: 145°F (63°C) heat only


This document is not intended to be used for installation purposes.

A05-111-01C

# Mounting Bracket For 800 Series Smoke Detector



# Wiring Diagram For 800 Series Detector



# System Sensor Worldwide Manufacturing & Distribution

System Sensor Headquarters 3825 Ohio Avenue St. Charles, IL 60174 Ph:800-SENSOR2 Fx:630/377-6495 Documents on Demand: 1-800-736-7672 × 3 Web:www.systemsensor.com **System Sensor in China**Ph: ++ 86.29.524.6253
Fx: ++ 86.29.524.6259
Web:www.systemsensor.com.cn

System Sensor in Europe Ph: ++ 44.1403.276500 Fx: ++ 44.1403.276501 System Sensor in Canada Ph: ++1.905.812.0767 Fx: ++1.905.812.0771

System Sensor in Singapore Ph: ++ 65.273.2230 Fx: ++ 65.273.2610 System Sensor - Far East Ph: ++ 852.2191.9003 Fx: ++ 852.2736.6580

System Sensor- Australia Ph: ++ 613.54.281.142 Fx: ++ 613.54.281.172